

How to read this list:		
Mark	Description	
X	Function is supported.	
*	Function is added or developed newly	

Function List										
Automaker:		Peugeot								
Software Version:		V6.6								
Automaker	Model	ECU Type	System	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions	
Peugeot	207	207 VAN	BSI						* Check of the coded engine immobiliser code in the built-in systems interface	
Peugeot	307	307 VAN	BSI						* Check of the coded engine immobiliser code in the built-in systems interface	
Peugeot	207	207 VAN	BSI						* Programming of keys	
Peugeot	307	307 VAN	BSI						* Programming of keys	
Peugeot	207	All the ECU Types	BSI						* Programming of BSI	
Peugeot	307	All the ECU Types	BSI						* Programming of BSI	
Peugeot	308	All the ECU Types	BSI						* Programming of BSI	
Peugeot	407	All the ECU Types	BSI						* Programming of BSI	
Peugeot	207	207 VAN	BSI						* Resetting to zero of the service mileage	
Peugeot	307	307 VAN	BSI						* Resetting to zero of the service mileage	
Peugeot	207	207 CAN	BSI						* Forcing of the fuel gauging data	
Peugeot	407	All the ECU Types	BSI						* Forcing of the fuel gauging data	
Peugeot	207	207 CAN							* Locking (Airbag)	

Peugeot	307	307 CAN							* Locking (Airbag)
Peugeot	308	All the ECU Types							* Locking (Airbag)
Peugeot	407	All the ECU Types							* Locking (Airbag)
Peugeot	207	207 CAN							* UnLocking (Airbag)
Peugeot	307	307 CAN							* UnLocking (Airbag)
Peugeot	308	All the ECU Types							* UnLocking (Airbag)
Peugeot	407	All the ECU Types							* UnLocking (Airbag)
Peugeot	207	207 CAN							* Configuration (Airbag)
Peugeot	307	307 CAN							* Configuration (Airbag)
Peugeot	308	All the ECU Types							* Configuration (Airbag)
Peugeot	407	All the ECU Types							* Configuration (Airbag)
Peugeot	207	207 CAN							* Maintenance (Instrument panel)
Peugeot	307	307 CAN							* Maintenance (Instrument panel)
Peugeot	308	All the ECU Types							* Maintenance (Instrument panel)
Peugeot	407	All the ECU Types							* Maintenance (Instrument panel)
Peugeot	207	207 CAN							* Configuration (Instrument panel)
Peugeot	307	307 CAN							* Configuration (Instrument panel)
Peugeot	308	All the ECU Types							* Configuration (Instrument panel)
Peugeot	206	All the ECU Types	Petrol Engine						Initializing the auto-adaptive
Peugeot	207	All the ECU Types	Petrol Engine						Initializing the auto-adaptive
Peugeot	307	All the ECU Types	Petrol Engine						Initializing the auto-adaptive
Peugeot	308	All the ECU Types	Petrol Engine						Initializing the auto-adaptive
Peugeot	407	All the ECU Types	Petrol Engine						Initializing the auto-adaptive
Peugeot	408	All the ECU Types	Petrol Engine						Initializing the auto-adaptive
Peugeot	207	All the ECU Types	ABS						Bleeding
Peugeot	307	All the ECU Types	ABS						Bleeding
Peugeot	308	All the ECU Types	ABS						Bleeding

Peugeot	407	All the ECU Types	ABS						Bleeding
Peugeot	408	All the ECU Types	ABS						Bleeding
Peugeot	206	All the ECU Types	ABS						Configuration for ABS
Peugeot	207	All the ECU Types	ABS						Configuration for ABS
Peugeot	307	All the ECU Types	ABS						Configuration for ABS
Peugeot	308	All the ECU Types	ABS						Configuration for ABS
Peugeot	407	All the ECU Types	ABS						Configuration for ABS
Peugeot	408	All the ECU Types	ABS						Configuration for ABS
Peugeot	207	All the ECU Types	BSI						Check of the coded engine immobiliser code in the built-in systems interface
Peugeot	307	All the ECU Types	BSI						Check of the coded engine immobiliser code in the built-in systems interface
Peugeot	308	All the ECU Types	BSI						Check of the coded engine immobiliser code in the built-in systems interface
Peugeot	407	All the ECU Types	BSI						Check of the coded engine immobiliser code in the built-in systems interface
Peugeot	207	All the ECU Types	BSI						Programming of keys
Peugeot	307	All the ECU Types	BSI						Programming of keys
Peugeot	308	All the ECU Types	BSI						Programming of keys
Peugeot	407	All the ECU Types	BSI						Programming of keys
Peugeot	207	All the ECU Types	BSI						Resetting to zero of the service mileage
Peugeot	307	All the ECU Types	BSI						Resetting to zero of the service mileage
Peugeot	308	All the ECU Types	BSI						Resetting to zero of the service mileage
Peugeot	407	All the ECU Types	BSI						Resetting to zero of the service mileage
Peugeot	308	All the ECU Types	BSI						Forcing of the fuel gauging data
Peugeot	206	All the ECU Types	Diesel Engine						Particulate filter regeneration
Peugeot	207	All the ECU Types	Diesel Engine						Particulate filter regeneration

Peugeot	307	All the ECU Types	Diesel Engine							Particulate filter regeneration
Peugeot	308	All the ECU Types	Diesel Engine							Particulate filter regeneration
Peugeot	407	All the ECU Types	Diesel Engine							Particulate filter regeneration
Peugeot	206	All the ECU Types	Diesel Engine							Replacement of the particle emission filter
Peugeot	207	All the ECU Types	Diesel Engine							Replacement of the particle emission filter
Peugeot	307	All the ECU Types	Diesel Engine							Replacement of the particle emission filter
Peugeot	308	All the ECU Types	Diesel Engine							Replacement of the particle emission filter
Peugeot	407	All the ECU Types	Diesel Engine							Replacement of the particle emission filter
Peugeot	206	All the ECU Types	Diesel Engine							Filling of the additive reservoir
Peugeot	207	All the ECU Types	Diesel Engine							Filling of the additive reservoir
Peugeot	307	All the ECU Types	Diesel Engine							Filling of the additive reservoir
Peugeot	308	All the ECU Types	Diesel Engine							Filling of the additive reservoir
Peugeot	407	All the ECU Types	Diesel Engine							Filling of the additive reservoir
Peugeot	206	All the ECU Types	Diesel Engine							Replacement of the additive reservoir, of the pump or of the pipes
Peugeot	207	All the ECU Types	Diesel Engine							Replacement of the additive reservoir, of the pump or of the pipes
Peugeot	307	All the ECU Types	Diesel Engine							Replacement of the additive reservoir, of the pump or of the pipes
Peugeot	308	All the ECU Types	Diesel Engine							Replacement of the additive reservoir, of the pump or of the pipes
Peugeot	407	All the ECU Types	Diesel Engine							Replacement of the additive reservoir, of the pump or of the pipes
Peugeot	1007 VAN	KFU MM6LP I	Petrol Engine	X	X	X	X	X		Initialising the autoadaptives
Peugeot	1007 VAN	KFU MM6LP II	Petrol Engine	X	X	X	X	X		Initialising the autoadaptives
Peugeot	1007 VAN	N6A BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X		Initialising the autoadaptives

Peugeot	1007 VAN	N6B BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	1007 VAN	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	1007 VAN	NFU ME7.4.4	Petrol Engine	X	X	X	X	X	
Peugeot	1007 VAN	KFV S2000PM2	Petrol Engine	X	X	X	X		
Peugeot	1007 VAN	KFV J34P	Petrol Engine	X	X	X	X	X	
Peugeot	1007 VAN	8HX SIEMENS SID 804	Diesel Engine	X	X	X	X		
Peugeot	1007 VAN	8HZ SIEMENS SID 804	Diesel Engine	X	X	X	X		
Peugeot	1007 VAN		ABS	X	X	X	X	X	Bleeding
Peugeot	1007 VAN	Controlled manual gearbox(BVMP)	Auto gearbox	X	X	X		X	
Peugeot	1007 VAN		Alarm ALARME	X	X	X	X	X	
Peugeot	1007 VAN		Radio RD3	X	X	X	X	X	
Peugeot	1007 VAN		Built-in system interface(BSI)	X	X	X	X		
Peugeot	1007 VAN		Instrument panel	X	X	X	X		
Peugeot	1007 VAN		Steering wheel switching module	X	X	X	X		
Peugeot	1007 VAN		Airbags	X	X	X	X		
Peugeot	1007 VAN		Air Conditioning	X	X	X	X		
Peugeot	1007 VAN	Multi-function display EMF	Display/Telematics	X	X	X	X	X	
Peugeot	1007 VAN		Parking assistance	X	X	X	X		
Peugeot	1007 VAN		CD player	X	X	X	X		
Peugeot	1007 VAN		Rain/brightness sensor	X	X	X			
Peugeot	1007 VAN		Sliding side doors module	X	X	X	X		
Peugeot	106R	CDY BOSCH MA3.1	Petrol Engine	X	X	X	X	X	
Peugeot	106R	CDZ BOSCH MA3.1	Petrol Engine	X	X	X	X	X	
Peugeot	106R	HDY BOSCH MA3.1	Petrol Engine	X	X	X	X	X	
Peugeot	106R	HDZ BOSCH MA3.1	Petrol Engine	X	X	X	X	X	
Peugeot	106R	HFX BOSCH M7.4.4	Petrol Engine	X	X	X	X	X	
Peugeot	106R	KFX BOSCH MP7.3	Petrol Engine	X	X	X	X		
Peugeot	106R	KFX MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	106R	NFX MM1AP	Petrol Engine	X	X	X	X	X	

Peugeot	106R	KFW SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	NFU BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	RFR MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	N6A BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	RFN MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	KFX BOSCH MP7.3	Petrol Engine	X	X	X	X		
Peugeot	206	KFX MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	206	KFU MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	206	RFN MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	206	HFY MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	206	HFZ MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	206	RFK MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	206	N6A BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	KFW SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	K6D SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	KFW BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	7LZ MM5NP	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	N6A BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	X	
Peugeot	206	NFU BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	KFW BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	KFW J34P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	K6D J34P	Petrol Engine	X	X	X	X	X	
Peugeot	206	NFU or N6A or N6B ME7.4.9 FLEX FUEL	Petrol Engine	X	X	X	X	X	
Peugeot	206	NFU J35	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	K6C MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	206	HFX MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	WJY LUCAS DCN2	Diesel Engine	X	X	X	X		
Peugeot	206	WJZ LUCAS DCN2	Diesel Engine	X	X	X	X		
Peugeot	206	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	Particle filter regeneration

Peugeot	206	9HZ BOSCH EDC16C3	Diesel Engine	X	X	X	X	X	Particle filter regeneration
Peugeot	206	8HX/8HZ BOSCH EDC16C3 EURO3	Diesel Engine	X	X	X	X	X	
Peugeot	206	8HZ BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	X	
Peugeot	206	9HY BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	X	
Peugeot	206	ABS BOSCH 5.3	ABS	X	X	X	X	X	Bleeding
Peugeot	206	ABS MK70	ABS	X	X	X	X	X	Bleeding
Peugeot	206	ABS TEVES	ABS	X	X	X	X	X	
Peugeot	206	ESP MK60	ABS	X	X	X	X		Bleeding
Peugeot	206	Auto Gearbox AL4	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	Auto Gearbox AL4 AT8	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	BVA AL4	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206	Airbag and seatbelts	Airbag	X	X	X			
Peugeot	206	Left side airbag	Airbag	X	X	X			
Peugeot	206	Right side airbag	Airbag	X	X	X			
Peugeot	206	SAC-CENT-AUTOLIV-2	Airbag	X	X	X			
Peugeot	206	BSI	Built-In System	X	X	X	X	X	1.Forcing of the customer mode 2.Resetting to zero of the service mileage 3.Configuration
Peugeot	206	BIS_SIEMENS	Built-In System	X	X	X	X	X	
Peugeot	206	AMF	Multi-function display	X	X	X	X	X	
Peugeot	206	AUTORADIO	Radio	X	X	X	X	X	
Peugeot	206	COMBINE_MM	Instrument panel	X	X	X	X	X	
Peugeot	206	COM2000	Steering wheel switching module	X	X	X	X		
Peugeot	206	ALARME_TEXTON	Alarm	X	X	X			
Peugeot	206		On-board navigation system	X	X	X	X	X	
Peugeot	206	CLIM_T12001	Air Conditioning	X	X	X	X	X	
Peugeot	206		Driving school	X			X	X	
Peugeot	206	CPT_PLUIE_LUM	Rain/brightness sensor	X	X	X			

Peugeot	206		Diesel fuel additive control unit	X	X	X	X	X	
Peugeot	206	TOUV_TEXTON	Sun roof	X	X	X	X	X	
Peugeot	206 MUX	NFU BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	RFR MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	N6A BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	RFN MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	KFX BOSCH MP7.3	Petrol Engine	X	X	X	X		
Peugeot	206 MUX	KFX MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	206 MUX	KFU MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	206 MUX	RFN MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	206 MUX	HFY MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	206 MUX	HFZ MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	206 MUX	RFK MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	206 MUX	N6A BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	KFW SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	K6D SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	KFW BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	7LZ MM5NP	Petrol Engine	X	X	X	X	X	
Peugeot	206 MUX	N6A BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	NFU BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	KFW BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	KFW J34P	Petrol Engine	X	X	X	X	X	
Peugeot	206 MUX	K6D J34P	Petrol Engine	X	X	X	X	X	
Peugeot	206 MUX	NFU or N6A or N6B ME7.4.9 FLEX FUEL	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	NFU J35	Petrol Engine	X	X	X	X	X	
Peugeot	206 MUX	K6C MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	206 MUX	HFX MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	WJY LUCAS DCN2	Diesel Engine	X	X	X	X		
Peugeot	206 MUX	WJZ LUCAS DCN2	Diesel Engine	X	X	X	X		

Peugeot	206 MUX	RHY BOSCH EDC15C2	Diesel Engine	*	*	*	*	*	Particle filter regeneration
Peugeot	206 MUX	9HZ BOSCH EDC16C3	Diesel Engine	X	X	X	X	X	Particle filter regeneration
Peugeot	206 MUX	8HX/8HZ BOSCH EDC16C3 EURO3	Diesel Engine	X	X	X	X	X	
Peugeot	206 MUX	8HZ BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	X	
Peugeot	206 MUX	9HY BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	X	
Peugeot	206 MUX	ABS BOSCH 5.3	ABS	X	X	X	X	X	Bleeding
Peugeot	206 MUX	ABS MK70	ABS	X	X	X	X	X	Bleeding
Peugeot	206 MUX	ABS TEVES	ABS	X	X	X	X		
Peugeot	206 MUX	ESP MK60	ABS	X	X	X	X	X	Bleeding
Peugeot	206 MUX	TEVES_MK20E	ABS	X	X	X	X	X	Bleeding
Peugeot	206 MUX	Auto Gearbox AL4	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	Auto Gearbox AL4 AT8	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	BVA AL4	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	206 MUX	Airbag and seatbelts	Airbag	X	X	X			
Peugeot	206 MUX	Left side airbag	Airbag	X	X	X			
Peugeot	206 MUX	Right side airbag	Airbag	X	X	X			
Peugeot	206 MUX	SAC-CENT-AUTOLIV-2	Airbag	X	X	X			
Peugeot	206 MUX	BSI	Built-In System	X	X	X	X	X	1.Forcing of the customer mode 2.Resetting to zero of the service mileage 3.Configuration
Peugeot	206 MUX	BIS_SIEMENS	Built-In System	X	X	X	X	X	
Peugeot	206 MUX	AMF	Multi-function display	X	X	X	X	X	
Peugeot	206 MUX	AUTORADIO	Radio	X	X	X	X	X	
Peugeot	206 MUX	COMBINE_MM	Instrument panel	X	X	X	X	X	
Peugeot	206 MUX	COM2000	Steering wheel switching module	X	X	X	X		
Peugeot	206 MUX	ALARME_TEXTON	Alarm	X	X	X			
Peugeot	206 MUX		On-board navigation system	X	X	X	X		
Peugeot	206 MUX	CLIM_T12001	Air Conditioning	X	X	X	X	X	
Peugeot	206 MUX		Driving school	X			X	X	
Peugeot	206 MUX	CPT_PLUIE_LUM	Rain/brightness sensor	X	X	X			

Peugeot	206 MUX		Diesel fuel additive control unit	X	X	X	X	X	
Peugeot	206 MUX	TOUV_TEXTON	Sun roof	X	X	X	X	X	
Peugeot	206+	RHY EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	207 VAN	NFU BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	RFR MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	N6A BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	RFN MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	KFX BOSCH MP7.3	Petrol Engine	X	X	X	X		
Peugeot	207 VAN	KFX MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	207 VAN	KFU MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	207 VAN	RFN MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	207 VAN	HFY MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	207 VAN	HFZ MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	207 VAN	RFK MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	207 VAN	N6A BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	KFW SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	K6D SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	KFW BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	7LZ MM5NP	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	N6A BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	X	
Peugeot	207 VAN	NFU BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	KFW BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	KFW J34P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	K6D J34P	Petrol Engine	X	X	X	X	X	
Peugeot	207 VAN	NFU or N6A or N6B ME7.4.9 FLEX FUEL	Petrol Engine	X	X	X	X	X	
Peugeot	207 VAN	NFU J35	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	K6C MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	207 VAN	HFX MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives

Peugeot	207 VAN	WJY LUCAS DCN2	Diesel Engine	X	X	X	X		
Peugeot	207 VAN	WJZ LUCAS DCN2	Diesel Engine	X	X	X	X		
Peugeot	207 VAN	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	Particle filter regeneration
Peugeot	207 VAN	9HZ BOSCH EDC16C3	Diesel Engine	X	X	X	X	X	Particle filter regeneration
Peugeot	207 VAN	8HX/8HZ BOSCH EDC16C3 EURO3	Diesel Engine	X	X	X	X	X	
Peugeot	207 VAN	8HZ BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	X	
Peugeot	207 VAN	9HY BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	X	
Peugeot	207 VAN	ABS BOSCH 5.3	ABS	X	X	X	X	X	Bleeding
Peugeot	207 VAN	ABS MK70	ABS	X	X	X	X	X	Bleeding
Peugeot	207 VAN	ABS TEVES	ABS	X	X	X	X	X	
Peugeot	207 VAN	ESP MK60	ABS	X	X	X	X		Bleeding
Peugeot	207 VAN	Auto Gearbox AL4	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	Auto Gearbox AL4 AT8	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	BVA AL4	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	207 VAN	Airbag and seatbelts	Airbag	X	X	X			
Peugeot	207 VAN	Left side airbag	Airbag	X	X	X			
Peugeot	207 VAN	Right side airbag	Airbag	X	X	X			
Peugeot	207 VAN	SAC-CENT-AUTOLIV-2	Airbag	X	X	X			
Peugeot	207 VAN	BSI	Built-In System	X	X	X	X	X	1.Programming of the build-in systems interface (Engine Immobilizer code and keys)
Peugeot	207 VAN	BIS_SIEMENS	Built-In System	X	X	X	X	X	
Peugeot	207 VAN	AMF	Multi-function display	X	X	X	X	X	
Peugeot	207 VAN	AUTORADIO	Radio	X	X	X	X	X	
Peugeot	207 VAN	COMBINE_MM	Instrument panel	X	X	X	X	X	
Peugeot	207 VAN	COM2000	Steering wheel switching module	X	X	X	X		
Peugeot	207 VAN	ALARME_TEXTON	Alarm	X	X	X			
Peugeot	207 VAN		On-board navigation system	X	X	X	X	X	
Peugeot	207 VAN	CLIM_T12001	Air Conditioning	X	X	X	X	X	

Peugeot	207 VAN		Driving school	X			X	X	
Peugeot	207 VAN	CPT_PLUIE_LUM	Rain/brightness sensor	X	X	X			
Peugeot	207 VAN		Diesel fuel additive control unit	X	X	X	X	X	
Peugeot	207 VAN	TOUV_TEXTON	Sun roof	X	X	X	X	X	
Peugeot	207	5FW MEV17.4	Petrol Engine	X	X	X	X	X	
Peugeot	207	8FS MEV17.4	Petrol Engine	X	X	X	X	X	
Peugeot	207	5FS MEV17.4	Petrol Engine	*	*	*	*	*	
Peugeot	207	MM6LPB	Petrol Engine	X	X	X	X	X	
Peugeot	207	NFS BOSCH ME7.4.5	Petrol Engine		X	X	X	X	
Peugeot	207	NFU BOSCH ME7.4.5	Petrol Engine		X	X	X	X	
Peugeot	207	MK70.1	ABS	X	X	X	X	X	1.Bleeding 2.Configuration
Peugeot	207	COMBINE_MM	Instrument Panel	X	X	X	X	X	1.Configuration 2.Maintenance
Peugeot	207	MK60-O	ABS	X	X	X	X	X	1. Calibration of the gyrometer accelerometer sensor 2.De-calibration of the steering wheel angle sensor 3.Steering wheel angle sensor calibration 4.Restyled_Configuration 5.not Restyled_Configuration 6.Bleeding
Peugeot	207	BSI	BSI	X	X	X	X	X	1.Check of the coded engine immobiliser code in the built-in systems interface 2.Programming of keys 3.Resetting to zero of the service mileage
Peugeot	207 Diesel	9HX BOSCH EDC 16C3 Common Rail	Engine		X	X	X	X	1.EGR throttle learning
Peugeot	207 Diesel	9HZ BOSCH EDC 16C34 Common Rail	Engine		X	X	X	X	1.EGR throttle learning
Peugeot	207 Diesel	8HZ BOSCH EDC 16C3 Common Rail	Engine		X	X	X	X	

Peugeot	207 Diesel	9HX BOSCH EDC 16C34 (K-LINE)	Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	207 Diesel	9HZ BOSCH EDC 16C34 (K-LINE)	Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	207	A/T AM6	AT		X	X	X	X	
Peugeot	207		ABS		X	X	X	X	
Peugeot	207	AirBag Control Unit	Airbag	X	X	X	X		1.Locking 2.Unlocking 3.Configuration
Peugeot	207		Steering column module		X	X	X	X	
Peugeot	207		SERVICE LIGHT RESET						1.Service Reset
Peugeot	207		Parking brake		X	X	X		
Peugeot	207i	RHY EDC15C2	Diesel Engine	*	*	*	*	*	
Peugeot	306	HDY BOSCH MA3.1	Petrol Engine	X	X	X	X	X	
Peugeot	306	HDZ BOSCH MA3.1	Petrol Engine	X	X	X	X	X	
Peugeot	306	KFX MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	306	RFS MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	306R	KFX BOSCH MP7.3	Petrol Engine	X	X	X	X		
Peugeot	306R	KFX MM1AP	Petrol Engine	X	X	X	X	X	

Peugeot	306R	KFX SAGEM SL96	Petrol Engine	X	X	X	X		
Peugeot	306R	LFY BOSCH MP7.3	Petrol Engine	X	X	X	X		
Peugeot	306R	LFY SAGEM SL96	Petrol Engine	X	X	X	X		
Peugeot	306R	NFT BOSCH M7.4.4	Petrol Engine	X	X	X	X	X	
Peugeot	306R	NFV BOSCH M7.4.4	Petrol Engine	X	X	X	X	X	
Peugeot	306R	RFS MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	306R	KFW SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	306R	K6D SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	306R	WJY LUCAS DCN2	Diesel Engine	X	X	X	X		
Peugeot	306R	WJZ LUCAS DCN2	Diesel Engine	X	X	X	X		
Peugeot	306R	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	306R		ABS	X	X	X	X	X	Bleeding
Peugeot	306R		Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	306R	Airbag and seatbelts	Airbag	X	X	X			
Peugeot	306R	Left side airbag	Airbag	X	X	X			
Peugeot	306R	Right side airbag	Airbag	X	X	X			
Peugeot	306R	CPH_TEXTON	Built-In System	X	X	X	X		
Peugeot	307 VAN	NFU BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	307 VAN	N6A BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	307 VAN	KFU MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	307 VAN	RFN MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	307 VAN	RFK MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	307 VAN	N6A BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	307 VAN	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	307 VAN	KFW SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	307 VAN	RFN MM48P(Mechanical throttle housing)	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	307 VAN		Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	307 VAN	K6D SAGEM S2000	Petrol Engine	X	X	X	X	X	
Peugeot	307 VAN	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	307 VAN	RHS BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	Particle filter regeneration

Peugeot	307 VAN	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	Particle filter regeneration
Peugeot	307 VAN	8HZ BOSCH EDC16C3	Diesel Engine	X	X	X	X	X	
Peugeot	307 VAN	9HX BOSCH EDC16C3	Diesel Engine	X	X	X	X	X	
Peugeot	307 VAN	9HZ BOSCH EDC16C3	Diesel Engine	X	X	X	X	X	1.Particle filter regeneration(stationary) 2.Particle filter regeneration(moving)
Peugeot	307 VAN	RHY SIEMENS SID 801	Diesel Engine	X	X	X	X	X	
Peugeot	307 VAN	9HY BOSCH EDC16C3 EURO4	Diesel Engine	X	X	X	X	X	
Peugeot	307 VAN	RHL SIEMENS SID 803	Diesel Engine	X	X	X	X	X	1.Particle filter regeneration(stationary) 2.Particle filter regeneration(moving)
Peugeot	307 VAN	RHR SIEMENS SID 803	Diesel Engine	X	X	X	X	X	1.Particle filter regeneration(stationary) 2.Particle filter regeneration(moving)
Peugeot	307 VAN	ABS8_BOSCH	ABS	X	X	X	X	X	Bleeding
Peugeot	307 VAN	ESP BOSCH 8	ABS	X	X	X	X	X	Bleeding
Peugeot	307 VAN	ESP BOSCH 5.7	ABS	X	X	X	X	X	Bleeding
Peugeot	307 VAN	TEVES_MK60_ABS	ABS	X	X	X	X		
Peugeot	307 VAN	ABS BOSCH 5.3	ABS	X	X	X	X	X	Bleeding
Peugeot	307 VAN	ABS BOSCH 8 (K-Line)	ABS	X	X	X	X		
Peugeot	307 VAN	ABS BOSCH 8 (CAN)		X	X	X	X		
Peugeot	307 VAN	Auto Gearbox 4PH20	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	307 VAN	BVA AL4	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	307 VAN	SAC Central	Airbag	X	X	X	X		
Peugeot	307 VAN	SAC_CENT_SIEMENS	Airbag	X	X	X			
Peugeot	307 VAN	CLIM T5	Air Conditioning	X	X	X	X	X	
Peugeot	307 VAN	BSI	Built-In System	X	X	X	X	X	1.Forcing of the customer mode 2.Resetting to zero of the service mileage
Peugeot	307 VAN	AMF	Multi-function display	X	X	X	X	X	

Peugeot	307 VAN	AUTORADIO	Radio	X	X	X	X	X	
Peugeot	307 VAN	CHANGEUR_CD	CD Player	X	X	X	X	X	
Peugeot	307 VAN	COMBINE_SAGEM	Instrument Panel	X	X	X	X	X	
Peugeot	307 VAN	GEP	Power Steering	X	X	X	X		
Peugeot	307 VAN	COM2000	Steering wheel switching module	X	X	X	X		
Peugeot	307 VAN	ALARME_TEXTON	Alarm	X	X	X			
Peugeot	307 VAN	TO_WEBASTO	Sun roof	X	X	X	X	X	
Peugeot	307 VAN	TOUV_TEXTON	Sun roof	X	X	X	X	X	
Peugeot	307 VAN	MDP_CONDUCT	Driver's door module	X	X	X	X		
Peugeot	307 VAN	MDP_PASSAG	Passenger door module	X	X	X	X		
Peugeot	307 VAN	BRET	Roll-over ECU	X	X	X	X		
Peugeot	307 VAN		Diesel fuel additive control unit	X	X	X	X	X	
Peugeot	307 VAN		Driving school	X			X	X	
Peugeot	307 CAN	RFJ MM6LPB	Petrol Engine	X	X	X	X	X	
Peugeot	307 CAN	KFU MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	307 CAN	RFK MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	307 CAN	RFN MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	307 CAN	N6A BOSCH ME7.4.5	Petrol Engine		X	X	X	X	
Peugeot	307 CAN	NFU BOSCH ME7.4.5	Petrol Engine		X	X	X	X	
Peugeot	307 CAN	9HZ BOSCH EDC 16C34 Common Rail	Desel Engine		X	X	X	X	1.EGR throttle learning 2.Particle filter regeneration
Peugeot	307 CAN	9HW BOSCH EDC 16C34	Desel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration

Peugeot	307 CAN	9HX BOSCH EDC 16C34	Desel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter regeneration 5.Particle filter replacement 6.Initializ. FAP filter additive quantity 7.Replace or fill additive tank 8.Replace metering pump 9.Tank filling
Peugeot	307 CAN	9HY BOSCH EDC 16C34	Desel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	307 CAN	2.0 SIMENS HDI SID803A[RHR]	Desel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	307 CAN	RHY BOSCH EDC15C2	Desel Engine	X	X	X	X	X	
Peugeot	307 CAN		ABS/ESP	X	X	X	X	X	
Peugeot	307 CAN		Automatic transmission control unit	X	X	X	X	X	
Peugeot	307 CAN	AirBag Control Unit	Air bag	X	X	X	X		1.Locking 2.Unlocking
Peugeot	307 CAN		Air Conditioning	X	X	X	X	X	
Peugeot	307 CAN		Built-In System	X	X	X	X	X	Resetting_zero_service
Peugeot	307 CAN		Multi-function display	X	X	X	X	X	
Peugeot	307 CAN		Instrument Panel	X	X	X	X	X	1.Configuration 2.Maintenance
Peugeot	307 CAN		Steering wheel switching module	X	X	X	X	X	
Peugeot	307 CAN		Alarm	X	X	X	X	X	

Peugeot	307 CAN		Driver's door module	X	X	X	X	X	
Peugeot	307 CAN		Passenger door module	X	X	X	X	X	
Peugeot	307 CAN		Rain/brightness sensor	X	X	X			
Peugeot	307 CAN		Parking assistance	X	X	X	X	X	
Peugeot	307 CAN		CD Player	X	X	X		X	
Peugeot	307 CAN		Power Steering	X	X	X	X		
Peugeot	307 CAN		Hand Free Kit	X	X	X	X	X	
Peugeot	308	BOSCH EDC 16C34	Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	308	BOSCH ABS 8.0	ABS		X	X	X	X	1.Steering angle calibration 2.Brake air bleed
Peugeot	308	TRW Autoliv AirBag	Airbag	X	X	X	X		1.Locking 2.Unlocking
Peugeot	308		ICM	X	X	X	X	X	1.Configuration 2.Maintenance
Peugeot	308		Steering column module		X	X	X	X	
Peugeot	308		SERVICE LIGHT RESET						1.Service Reset
Peugeot	308	ABS 8.1	ABS	X	X	X	X	X	1.Configuration 2.Bleeding
Peugeot	308	BSI	BSI	X	X	X	X	X	1.BSI_KeyLearning 2.Resetting to zero of the service mileage 3.Check of the coded engine immobiliser code in the built-in systems interface
Peugeot	405	LFZ SAGEM S2000	Petrol Engine	X	X	X	X		
Peugeot	405	1600RD SAGEM S2000	Petrol Engine	X	X	X	X		

Peugeot	405	N6A ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	405	N6B ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	405	NFU ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	405	LFY BOSCH MP7.3	Petrol Engine	X	X	X	X		
Peugeot	406	KFX SAGEM SL96	Petrol Engine	X	X	X	X		
Peugeot	406	XFX BOSCH ME7.4.6	Petrol Engine	X	X	X	X	X	
Peugeot	406	3FZ MM4MP2	Petrol Engine	X	X	X	X		Initialising the autoadaptives
Peugeot	406	RFR MM4.8P	Petrol Engine	X	X	X	X	X	
Peugeot	406	RLZ SIEMENS SIRIUS 81	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406	LFY BOSCH MP7.3	Petrol Engine	X	X	X	X		Initialising the autoadaptives
Peugeot	406	LFY SAGEM SL96	Petrol Engine	X	X	X	X		
Peugeot	406	LFX MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	406	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	406	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	406		ABS	X	X	X	X	X	Bleeding
Peugeot	406		Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406	Airbag and seatbelts	Airbag	X	X	X			
Peugeot	406	Left side airbag	Airbag	X	X	X			
Peugeot	406	Right side airbag	Airbag	X	X	X			
Peugeot	406R	KFX SAGEM SL96	Petrol Engine	X	X	X	X		
Peugeot	406R	XFX BOSCH ME7.4.6	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R	3FZ MM4MP2	Petrol Engine	X	X	X	X		
Peugeot	406R	RFR MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R	RLZ SIEMENS SIRIUS 81	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R	LFY BOSCH MP7.3	Petrol Engine	X	X	X	X		
Peugeot	406R	R6F MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R	LFY SAGEM SL96	Petrol Engine	X	X	X	X		
Peugeot	406R	LFX MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	406R	RLZ IDE SIRIUS 81	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R	6FZ SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R	RFN MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives

Peugeot	406R	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	406R	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	406R	RHS BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	406R	RHY SIEMENS SID 801	Diesel Engine	X	X	X	X	X	
Peugeot	406R	4HX BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	406R	ABR5.3	ABS	X	X	X	X	X	Bleeding
Peugeot	406R	BVA_AL4	Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R	BVA_AL41	Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R	Auto Gearbox 4HP20	Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R	Auto Gearbox AL4	Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R	Auto Gearbox AL4 AT8	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R	BVA_ZF	Auto Gearbox	X	X	X	X	X	
Peugeot	406R	SAC_ACK	Airbag	X	X	X	X		
Peugeot	406R	SAC_CENT_AUTOLIV_2	Airbag	X	X	X			
Peugeot	406R	BSI	Built-in system interface	X	X	X	X	X	
Peugeot	406R	BSI_SIEMENS	Built-in system interface	X	X	X	X	X	
Peugeot	406R	CLIM_D92001	Air Conditioning	X	X	X	X	X	
Peugeot	406R	CLIM_D9	Air Conditioning	X	X	X	X	X	
Peugeot	406R	AMF	Multi-function display	X	X	X	X	X	
Peugeot	406R	AUTORADIO	Radio	X	X	X	X	X	
Peugeot	406R	COMBINE_VDO	Instrument panel	X	X	X	X	X	
Peugeot	406R	SIEGE_BITRON	Seat and mirrors with memory	X	X	X	X		
Peugeot	406R		Alarm	X	X	X			
Peugeot	406R	DVA_ZF	Power Steering	X	X	X			
Peugeot	406R	CD player	CD player	X	X	X	X	X	
Peugeot	406R		On-board navigation system	X	X	X	X		
Peugeot	406R		Diesel fuel additive control unit	X	X	X	X		
Peugeot	406R		Rain/brightness sensor	X	X	X			
Peugeot	406R Coupe	KFX SAGEM SL96	Petrol Engine	X	X	X	X		

Peugeot	406R Coupe	XFX BOSCH ME7.4.6	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	3FZ MM4MP2	Petrol Engine	X	X	X	X		
Peugeot	406R Coupe	RFR MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	RLZ SIEMENSSIRIUS 81	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	LFY BOSCH MP7.3	Petrol Engine	X	X	X	X		
Peugeot	406R Coupe	R6F MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	LFY SAGEM SL96	Petrol Engine	X	X	X	X		
Peugeot	406R Coupe	LFX MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	406R Coupe	RLZ IDE SIRIUS 81	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	6FZ SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	RFN MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	406R Coupe	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	406R Coupe	RHS BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	406R Coupe	RHY SIEMENS SID 801	Diesel Engine	X	X	X	X	X	
Peugeot	406R Coupe	4HX BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	406R Coupe	ABS ABR5.3	ABS	X	X	X	X	X	Bleeding
Peugeot	406R Coupe	BVA_AL4	Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	BVA_AL41	Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	Auto Gearbox 4HP20	Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	Auto Gearbox AL4	Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	Auto Gearbox AL4 AT8	AT	X	X	X	X	X	Initialising the autoadaptives
Peugeot	406R Coupe	Auto Gearbox	Auto Gearbox	X	X	X	X	X	
Peugeot	406R Coupe	BVA_ZF	Auto Gearbox	X	X	X	X	X	
Peugeot	406R Coupe	SAC_ACK	Airbag	X	X	X	X		
Peugeot	406R Coupe	SAC_CENT_AUTOLIV_2	Airbag	X	X	X			
Peugeot	406R Coupe	BSI	Built-in system interface	X	X	X	X	X	
Peugeot	406R Coupe	BSI_SIEMENS	Built-in system interface	X	X	X	X	X	
Peugeot	406R Coupe	CLIM_D92001	Air Conditioning	X	X	X	X	X	
Peugeot	406R Coupe	CLIM_D9	Air Conditioning	X	X	X	X	X	
Peugeot	406R Coupe	AMF	Multi-function display	X	X	X	X	X	

Peugeot	406R Coupe	AMF1	Multi-function display	X	X	X	X	X	
Peugeot	406R Coupe	AUTORADIO	Radio	X	X	X	X	X	
Peugeot	406R Coupe	COMBINE_VDO	Instrument panel	X	X	X	X	X	
Peugeot	406R Coupe	COMBINE_VDO1	Instrument panel	X	X	X	X	X	
Peugeot	406R Coupe	SIEGE_BITRON	Seat and mirrors with memory	X	X	X	X		
Peugeot	406R Coupe		Alarm	X	X	X			
Peugeot	406R Coupe	DVA_Z	Power Steering	X	X	X			
Peugeot	406R Coupe		CD player On-board	X	X	X	X	X	
Peugeot	406R Coupe		navigation system	X	X	X	X		
Peugeot	406R Coupe		Diesel fuel additive control unit	X	X	X	X		
Peugeot	406R Coupe		Rain/brightness sensor	X	X	X			
Peugeot	407	RFN MM6LP	Petrol Engine	X	X	X	X		
Peugeot	407	RFJ MM6LPB	Petrol Engine		X	X	X	X	
Peugeot	407	6FY MM6LPB	Petrol Engine		X	X	X	X	
Peugeot	407	EDC17CP11	Diesel Engine	X	X	X	X		
Peugeot	407	9HY BOSCH EDC16C3 EURO3 (CANBUS)	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration

Peugeot	407	9HY BOSCH EDC16C3 EURO3 (K-Line)	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	407	9HZ BOSCH EDC16C3	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle initial. and intake air heat.
Peugeot	407	9HZ BOSCH EDC 16C34(Canbus)	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle initial. and intake air heat.
Peugeot	407	9HZ BOSCH EDC 16C34(k-Line)	Diesel Engine	X	X	X	X	X	
Peugeot	407	4HP BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	4HR BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	4HS BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	4HT BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	RHL DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	RHR DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	RHF DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	UHZ SIEMENS SID201	Diesel Engine	X	X	X	X		
Peugeot	407	RHR SIEMENS SID 803(Canbus)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump

Peugeot	407	RHR SIEMENS SID 803(k-Line)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHL SIEMENS SID 803(Canbus)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHL SIEMENS SID 803(k-Line)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	AM6 automatic gearbox	Gearbox		X	X	X	X	
Peugeot	407	Built-in systems interface	BSI	X	X	X	X	X	1.KeyLearning 2.BSI_Check of the coded engine immobiliser code in the built-in systems interface 3.Resetting to zero of the service mileage
Peugeot	407	TEVES ABS MK60(Canbus)	ABS/ESP		X	X	X	X	
Peugeot	407	TEVES ABS MK60(K-Line)	ABS/ESP		X	X	X	X	
Peugeot	407	ESP 8.1	ABS/ESP	X	X	X	X	X	1.Restrictor Calibration of the gyrometer accelerometer sensor 2.Restrictor_Calibration of the steering wheel angle sensor 3.Configuration 4.Bleeding
Peugeot	407	TRW Autoliv AirBag	Airbag	X	X	X	X	X	1.Locking 2.Unlocking
Peugeot	407	Instrument panel	ICM	X	X	X	X	X	1.Maintenance
Peugeot	407	Parking Brake	Parking Brake		X	X	X		
Peugeot	407	Clima	Clima		X	X	X		

Peugeot	407	Service Light Reset	Service Light Reset						1.Service Reset
Peugeot	407	k-Line	Diesel addition		X	X	X	X	
Peugeot	407	Canbus	Diesel addition		X	X	X	X	
Peugeot	407	Switch module at the steering wheel	Steering Column Module		X	X	X	X	
Peugeot	407	RFN MM6LP	Petrol Engine	X	X	X	X		
Peugeot	407	RFJ MM6LPB	Petrol Engine		X	X	X	X	
Peugeot	407	6FY MM6LPB	Petrol Engine		X	X	X	X	
Peugeot	407	EDC17CP11	Diesel Engine	X	X	X	X		
Peugeot	407	9HY BOSCH EDC16C3 EURO3 (CANBUS)	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	407	9HY BOSCH EDC16C3 EURO3 (K-Line)	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration

Peugeot	407	9HZ BOSCH EDC16C3	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle initial. and intake air heat.
Peugeot	407	9HZ BOSCH EDC 16C34(Canbus)	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle initial. and intake air heat.
Peugeot	407	9HZ BOSCH EDC 16C34(k-Line)	Diesel Engine	X	X	X	X	X	
Peugeot	407	4HP BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	4HR BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	4HS BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	4HT BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	RHL DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	RHR DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	RHF DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	UHZ SIEMENS SID201	Diesel Engine	X	X	X	X		
Peugeot	407	RHR SIEMENS SID 803(Canbus)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHR SIEMENS SID 803(k-Line)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHL SIEMENS SID 803(Canbus)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHL SIEMENS SID 803(k-Line)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	AM6 automatic gearbox	Gearbox		X	X	X	X	

Peugeot	407	Built-in systems interface	BSI	X	X	X	X	X	1.KeyLearning 2.BSI_Check of the coded engine immobiliser code in the built-in systems interface 3.Resetting to zero of the service mileage
Peugeot	407	TEVES ABS MK60(Canbus)	ABS/ESP		X	X	X	X	
Peugeot	407	TEVES ABS MK60(K-Line)	ABS/ESP		X	X	X	X	
Peugeot	407	ESP 8.1	ABS/ESP	X	X	X	X	X	1.Restrictor Calibration of the gyrometer accelerometer sensor 2.Restrictor_Calibration of the steering wheel angle sensor 3.Configuration 4.Bleeding
Peugeot	407	TRW Autoliv AirBag	Airbag	X	X	X	X	X	1.Locking 2.Unlocking
Peugeot	407	Instrument panel	ICM	X	X	X	X	X	1.Maintenance
Peugeot	407	Parking Brake	Parking Brake		X	X	X		
Peugeot	407	Clima	Clima		X	X	X		
Peugeot	407	Service Light Reset	Service Light Reset						1.Service Reset
Peugeot	407	k-Line	Diesel addition		X	X	X	X	
Peugeot	407	Canbus	Diesel addition		X	X	X	X	
Peugeot	407	Switch module at the steering wheel	Steering Column Module		X	X	X	X	
Peugeot	407	RFN MM6LP	Petrol Engine	X	X	X	X		
Peugeot	407	EDC17CP11	Diesel Engine	X	X	X	X		
Peugeot	407	UHZ SIEMENS SID201	Diesel Engine	X	X	X	X		

Peugeot	407	RHR SIEMENS SID 803(Canbus)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHR SIEMENS SID 803(k-Line)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHL SIEMENS SID 803(Canbus)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHL SIEMENS SID 803(k-Line)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHL DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	RHR DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	AM6 automatic gearbox	Gearbox		X	X	X	X	
Peugeot	407	Built-in systems interface	BSI	X	X	X	X	X	1.KeyLearning 2.BSI_Check of the coded engine immobiliser code in the built-in systems interface 3.Resetting to zero of the service mileage
Peugeot	407	TEVES ABS MK60(Canbus)	ABS/ESP		X	X	X	X	
Peugeot	407	TEVES ABS MK60(K-Line)	ABS/ESP		X	X	X	X	
Peugeot	407	ESP 8.1	ABS/ESP	X	X	X	X	X	1.Restrictor Calibration of the gyrometer accelerometer sensor 2.Restrictor_Calibration of the steering wheel angle sensor 3.Configuration 4.Bleeding

Peugeot	407	TRW Autoliv AirBag	Airbag	X	X	X	X	X	1.Locking 2.Unlocking
Peugeot	407	Instrument panel	ICM	X	X	X	X	X	1.Maintenance
Peugeot	407	Parking Brake	Parking Brake		X	X	X		
Peugeot	407	Clima	Clima		X	X	X		
Peugeot	407	Service Light Reset	Service Light Reset						1.Service Reset
Peugeot	407	k-Line	Diesel addition		X	X	X	X	
Peugeot	407	Canbus	Diesel addition		X	X	X	X	
Peugeot	407	Switch module at the steering wheel	Steering Column Module		X	X	X	X	
Peugeot	407	RFN MM6LP	Petrol Engine	X	X	X	X		
Peugeot	407	RFJ MM6LPB	Petrol Engine		X	X	X	X	
Peugeot	407	6FY MM6LPB	Petrol Engine		X	X	X	X	
Peugeot	407	*	Petrol Engine	*	*	*	*	*	
Peugeot	407	EDC17CP11	Diesel Engine	X	X	X	X		
Peugeot	407	9HY BOSCH EDC16C3 EURO3 (CANBUS)	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	407	9HY BOSCH EDC16C3 EURO3 (K-Line)	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity

Peugeot	407	9HZ BOSCH EDC16C3	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle initial. and intake air heat.
Peugeot	407	9HZ BOSCH EDC 16C34(Canbus)	Diesel Engine		X	X	X	X	1.EGR SV learning 2.EGR throttle initial. and intake air heat.
Peugeot	407	9HZ BOSCH EDC 16C34(k-Line)	Diesel Engine	X	X	X	X	X	
Peugeot	407	4HP BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	4HR BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	4HS BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	4HT BOSCH EDC16CP39	Diesel Engine	X	X	X	X		
Peugeot	407	RHL DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	RHR DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	RHF DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	UHZ SIEMENS SID201	Diesel Engine	X	X	X	X		
Peugeot	407	RHR SIEMENS SID 803(Canbus)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHR SIEMENS SID 803(k-Line)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHL SIEMENS SID 803(Canbus)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump

Peugeot	407	RHL SIEMENS SID 803(k-Line)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	AM6 automatic gearbox	Gearbox		X	X	X	X	
Peugeot	407	Built-in systems interface	BSI	X	X	X	X	X	1.KeyLearning 2.BSI_ Check of the coded engine immobiliser code in the built-in systems interface 3.Resetting to zero of the service mileage
Peugeot	407	TEVES ABS MK60(Canbus)	ABS/ESP		X	X	X	X	
Peugeot	407	TEVES ABS MK60(K-Line)	ABS/ESP		X	X	X	X	
Peugeot	407	ESP 8.1	ABS/ESP	X	X	X	X	X	1.Restrictor Calibration of the gyrometer accelerometer sensor 2.Restrictor Calibration of the
Peugeot	407	TRW Autoliv AirBag	Airbag	X	X	X	X	X	1.Locking 2.Unlocking
Peugeot	407	Instrument panel	ICM	X	X	X	X	X	1.Maintenance
Peugeot	407	Parking Brake	Parking Brake		X	X	X		
Peugeot	407	Clima	Clima		X	X	X		
Peugeot	407	Service Light Reset	Service Light Reset						1.Service Reset
Peugeot	407	k-Line	Diesel addition		X	X	X	X	
Peugeot	407	Canbus	Diesel addition		X	X	X	X	
Peugeot	407	Switch module at the steering wheel	Steering Column Module		X	X	X	X	
Peugeot	407	RFN MM6LP	Petrol Engine	X	X	X	X		

Peugeot	407	EDC17CP11	Diesel Engine	X	X	X	X		
Peugeot	407	UHZ SIEMENS SID201	Diesel Engine	X	X	X	X		
Peugeot	407	RHR SIEMENS SID 803(Canbus)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHR SIEMENS SID 803(k-Line)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHL SIEMENS SID 803(Canbus)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	RHL SIEMENS SID 803(k-Line)	Diesel Engine		X	X	X	X	1.Particle filter regeneration 2.Replace or fill additive tank
Peugeot	407	RHL DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	RHR DCM3.4	Diesel Engine	X	X	X	X		
Peugeot	407	AM6 automatic gearbox	Gearbox		X	X	X	X	
Peugeot	407	Built-in systems interface	BSI	X	X	X	X	X	1.KeyLearning 2.BSI_Check of the coded engine immobiliser code in the built-in
Peugeot	407	TEVES ABS MK60(Canbus)	ABS/ESP		X	X	X	X	
Peugeot	407	TEVES ABS MK60(K-Line)	ABS/ESP		X	X	X	X	
Peugeot	407	ESP 8.1	ABS/ESP	X	X	X	X	X	1.Restrictor Calibration of the gyrometer accelerometer sensor 2.Restrictor Calibration of the
Peugeot	407	TRW Autoliv AirBag	Airbag	X	X	X	X	X	1.Locking 2.Unlocking
Peugeot	407	Instrument panel	ICM	X	X	X	X	X	1.Maintenance

Peugeot	407	Parking Brake	Parking Brake		X	X	X		
Peugeot	407	Clima	Clima		X	X	X		
Peugeot	407	Service Light Reset	Service Light Reset						1.Service Reset
Peugeot	407	k-Line	Diesel addition		X	X	X	X	
Peugeot	407	Canbus	Diesel addition		X	X	X	X	
Peugeot	407	Switch module at the steering wheel	Steering Column Module		X	X	X	X	
Peugeot	408	NFU ME749 Bio Flex	Engine	X	X	X	X		
Peugeot	408	RFJ MM6LPB	Engine	X	X	X	X		
Peugeot	408	TU5JP4 ME745	Engine	X	X	X	X		
Peugeot	408	Instrument Panel	Instrument Panel	X	X	X	X		
Peugeot	408	ABS 8.1	ABS/ESP	X	X	X	X		
Peugeot	408	ESP8.1	ABS/ESP	X	X	X	X		
Peugeot	408	Airbag(China)	Airbag	X	X	X	X		
Peugeot	408	Airbag(Mercosur)	Airbag	X	X	X	X		
Peugeot	408	BSI	BSI	X	X	X	X		
Peugeot	408	AT AL4AT8	Gearbox	X	X	X	X		
Peugeot	607	3FZ MM4MP2	Petrol Engine	X	X	X	X		
Peugeot	607	R6F MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	607	RFN MM48P(Mechanical throttle housing)	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	607		Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	607	XFX BOSCH ME7.4.6	Petrol Engine	X	X	X	X	X	
Peugeot	607	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	607	RHS BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	607	4HX BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	607		ABS	X	X	X	X	X	Bleeding
Peugeot	607		Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	607		Airbag	X	X	X			
Peugeot	607		Air Conditioning	X	X	X	X		

Peugeot	806	R6F MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	806	RFN MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	806	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	806	RHW BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	806	Airbag and seatbelts	Airbag	X	X	X	X	X	
Peugeot	806	BOSCH ABS 5.3	ABS	X	X	X			Bleeding
Peugeot	807 VAN	3FZ MM4MP2	Petrol Engine	X	X	X	X		
Peugeot	807 VAN	3FZ MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	807 VAN	RFN MM6LP	Petrol Engine	X	X	X	X	X	
Peugeot	807 VAN	XFW BOSCH ME746	Petrol Engine	X	X	X	X		
Peugeot	807 VAN	R6F MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	807 VAN	RFN MM48P(Mechanical throttle housing)	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	807 VAN	RHW BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	807 VAN	RHT BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	807 VAN	RHM BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	807 VAN	4HW BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	807 VAN	ESP BOSCH 5.7	ABS	X	X	X	X	X	Bleeding
Peugeot	807 VAN	BVA_AL4	Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	807 VAN	4PH20 automatic gearbox	Auto Gearbox	X	X	X	X	X	Initialising the autoadaptives
Peugeot	807 VAN		Airbag	X	X	X			
Peugeot	807 VAN	Climate control	Air Conditioning	X	X	X	X	X	
Peugeot	807 VAN		Multi-function display	X	X	X	X	X	
Peugeot	807 VAN		Instrument panel	X	X	X	X	X	
Peugeot	807 VAN		Steering wheel switching module	X	X	X	X		
Peugeot	807 VAN		Alarm	X	X	X			
Peugeot	807 VAN	AUTORADIO	Radio	X	X	X	X	X	
Peugeot	807 VAN		Driver's door module	X	X	X	X		
Peugeot	807 VAN		Passenger door module	X	X	X	X		
Peugeot	807 VAN		CD player	X	X	X	X	X	

Peugeot	807 VAN		Diesel fuel additive control unit	X	X	X	X	X	
Peugeot	BOXER	MM48P 2L essence plombée	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	BOXER	ABS/ESP	ABS	X	X	X	X	X	Bleeding
Peugeot	BOXER 3	4HU PUMA DCU102	Engine	X	X	X	X	X	
Peugeot	BOXER 3	4HV PUMA DCU102	Engine	X	X	X	X	X	
Peugeot	BOXER 3	Sofim 3.0 145cv	Engine	X	X	X		X	
Peugeot	BOXER 3	Sofim 3.0 145cv FAP	Engine	X	X	X		X	
Peugeot	EXPERT	R6F MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	EXPERT	RFN MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	EXPERT	RHZ BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	EXPERT	WJY LUCAS DCN2	Diesel Engine	X	X	X	X		
Peugeot	EXPERT	RHW BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	EXPERT	RHX BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	EXPERT	BOSCH ABS5.3	ABS	X	X	X	X	X	Bleeding
Peugeot	EXPERT	BOSCH ABS5.3	Airbag	X	X	X			
Peugeot	PARTNER	HDY BOSCH MA3.1	Petrol Engine	X	X	X	X	X	
Peugeot	PARTNER	HDZ BOSCH MA3.1	Petrol Engine	X	X	X	X	X	
Peugeot	PARTNER	HFX BOSCH M7.4.4	Petrol Engine	X	X	X	X	X	
Peugeot	PARTNER	KFX BOSCH MP7.3	Petrol Engine	X	X	X	X		
Peugeot	PARTNER	KFX MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	PARTNER	KFX SGEAM SL96	Petrol Engine	X	X	X	X		
Peugeot	PARTNER	LFX MM1AP	Petrol Engine	X	X	X	X	X	
Peugeot	PARTNER	N6A BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	PARTNER	NFU BOSCH ME7.4.4	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	PARTNER	K6D SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	PARTNER	KFW SAGEM S2000	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	PARTNER	N6A BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	PARTNER	NFU BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	PARTNER	N6B BOSCH ME7.4.5	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	PARTNER	KFW J34P	Petrol Engine	X	X	X	X	X	

Peugeot	PARTNER	KFW SAGEM S2000PM1	Petrol Engine	X	X	X	X	X	
Peugeot	PARTNER	HFX MM4.8P	Petrol Engine	X	X	X	X	X	Initialising the autoadaptives
Peugeot	PARTNER	WJY LUCAS DCN2	Diesel Engine	X	X	X	X		
Peugeot	PARTNER	WJZ LUCAS DCN2	Diesel Engine	X	X	X	X		
Peugeot	PARTNER	RHY BOSCH EDC15C2	Diesel Engine	X	X	X	X	X	
Peugeot	PARTNER	RHY SIEMENS SID 801	Diesel Engine	X	X	X	X	X	
Peugeot	PARTNER	9HX BOSCH EDC16C3	Diesel Engine	X	X	X	X	X	
Peugeot	PARTNER	9HW BOSCH EDC16C3	Diesel Engine	X	X	X	X	X	
Peugeot	PARTNER	ALARME_TEXTON	Alarm	X	X	X			
Peugeot	PARTNER	COM2000	Steering wheel switching module	X	X	X	X		
Peugeot	PARTNER	AUTORADIO	Radio	X	X	X	X	X	
Peugeot	PARTNER	COMBINE_MM	Instrument panel	X	X	X	X	X	
Peugeot	PARTNER	BSI	Built-in system interface(BSI)	X	X	X	X	X	
Peugeot	PARTNER	BSI1	Built-in system interface(BSI)	X	X	X	X	X	1.Forcing of the customer mode 2.Resetting to zero of the service mileage
Peugeot	PARTNER	ESP BOSCH 5.7	ABS	X	X	X	X	X	Bleeding
Peugeot	PARTNER	ABS BOSCH 8	ABS	X	X	X	X	X	Bleeding
Peugeot	PARTNER	ESP BOSCH 8	ABS	X	X	X	X	X	Bleeding
Peugeot	PARTNER	ABS 8.1	ABS	X	X	X	X	X	Bleeding
Peugeot	PARTNER	Airbag and seatbelts	Airbag	X	X	X	X		
Peugeot	PARTNER	SAC_CENT_AUTOLIV	Airbag	X	X	X			
Peugeot	PARTNER		Display/Telematics	X	X	X	X	X	
Peugeot	PARTNER		CD player	X	X	X	X	X	
Peugeot	PARTNER		Rain/brightness sensor	X	X	X			
Peugeot	PARTNER 2	BOSCH ME 7.4.5	Engine		X	X	X	X	

Peugeot	PARTNER 2	9HW BOSCH EDC 16C34	Engine		X	X	X	X	<ul style="list-style-type: none"> 1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	PARTNER 2	BOSCH ABS 8.1	ABS		X	X	X	X	
Peugeot	PARTNER 2		Airbag		X	X	X	X	
Peugeot	PARTNER 2		SERVICE LIGHT RESET						1.Service Reset